

## 3500369 Adult Upholstery to Pediatric Top Conversion Kit 3500408 Pediatric Top to Adult Upholstery Conversion Kit

**3500369**

Item No.	Description	Qty
1	Pediatric Upholstery Assembly	1
2	Pediatric Top Mounting Plate	1
3	Round Thumb Screw 10-24 x 3/4"	2
4	Screw 1/4-20 x 3/4"	2
5	Plastic-Head Thumb Screw 10-24 x 5/8"	3
6	Lock Washer Screw 1/4-20 x 3/8"	2
7	Pry Bar	1

**3500408**

Item No.	Description	Qty
1	Adult Upholstery Assembly	1
2	Plastic-Head Thumb Screw 10-24 x 5/8"	3
3	Screw 10-24 x 1"	4
4	Hex Nut 10-24	2
5	Support Bracket	1
6	Push Rivet	7
7	Top Cover	1
8	Gas Spring Cylinder	1
9	Round Thumb Screw 10-24 x 3/4"	2
10	Cylinder Clevis	1
11	Cotter Pin	2
12	Clevis Pin 1/4" Dia. 1-7/8" Long	2
13	Upholstery Bumper	2

**Tools Required**

- Phillips Screwdriver
- Pry Bar (Included in kit)
- 7/16" Socket Wrench


*Hardware shown not to scale.*

Registering your Brewer product is easy.  
Simply go to [brewercompany.com/warranty-registration](http://brewercompany.com/warranty-registration), fill out the information fields and click send.  
By registering your product today, you are better safeguarding your investment in the future.


**The Brewer Company, LLC**  
N88 W13901 Main Street, Suite 100  
Menomonee Falls, WI 53051  
P 1.888.Brewer.1  
F 262.251.2332  
E [customerservice@brewercompany.com](mailto:customerservice@brewercompany.com)  
[www.brewercompany.com](http://www.brewercompany.com)

**3500369 Removing the Existing Adult Upholstery**


1. Remove paper roll holder by removing round thumb screws. Save hardware and paper roll holder for reinstallation.




2. Remove clevis pin for gas cylinder.




3. Rest gas cylinder on top cover plate.




4. Lower upholstered backrest and raise upholstered seat. Remove two end thumb screws and loosen but do not remove center thumb screw.




5. Lift straight up and remove upholstery.





6. Remove top cover rivets with supplied pry bar. Remove top cover.





7. Remove gas cylinder lower clevis pin and remove gas spring.





8. Remove rear leg extension bumper and remove leg extension. Save hardware for reinstallation.




9. Remove front bumpers. Remove both pelvic tilt bar screws and pelvic tilt bar, if present.



10. Remove support bracket and clevis.




11. Table is ready for pediatric top installation.





**Attaching the Pediatric Top**

*NOTE: Numbers in the text refer to the items in the 3500369 parts list on page 1.*



1. Remove toe pad, debris pan and front bumper from leg extension. Save hardware for reinstallation.




2. Insert leg extension and attach rear bumper.





3. Place pediatric top mounting plate (2) on table so vertical plate slides into the table's attachment system. Fasten two end thumb screws and tighten all three, using new thumb screws if needed (3).




4. Secure the rear of the pediatric mounting plate using the two 1/4-20 x 3/8" lockwasher screws (6).




5. Place pediatric top (1) on mounting plate using front hex screws. Guide hex screws into keyhole slots and push pediatric top towards the front of the table. Make sure hex screws are all the way into the keyhole slots, then tighten (push leg extension in as required to get at hex screws).




6. Secure the rear of the pediatric top using the two 1/4-20 x 3/4" screws (4).




7. Pull out leg extension and re-install front bumper.



8. Insert debris pan and drop in toe board.




9. Fasten paper roll holder in desired orientation with round thumb screws. Replace round thumb screws (3) with new ones if necessary.




## 3500408 Removing the Pediatric Top


1. Pull out leg extension and remove toe pad and debris pan.




2. Remove leg extension front bumper. Save hardware for reinstallation.






3. Push leg extension in to access pediatric top front mounting hex screws.




4. Remove paper roll holder by unscrewing the two round thumb screws. Save hardware and paper roll holder for reinstallation.





5. Loosen the pediatric top front hex screws and remove rear screws. Slide pediatric top towards the rear of the table so the front hex screws can clear the keyhole openings in the mounting plate. Remove the pediatric top.




6. Remove back two pediatric top mounting screws.



7. Loosen center thumb screw. Remove the other two thumb screws and remove pediatric mounting plate.




8. Table is now ready for the adult upholstery top.




## Attaching the Adult Upholstery

*NOTE: Numbers in the text refer to the items in the 3500408 parts list on page 1.*



1. Attach the two front bumpers (13) to the table with 10-24 x 1" screws (3).



2. Attach the support bracket (5) and cylinder clevis (10) using two 10-24 x 1" screws (3) and two 10-24 hex nuts (4).




3. Place debris pan and toe board on leg extension. Insert leg extension into table and attach rear leg extension bumper.








4. Attach gas spring cylinder (8) to cylinder clevis (10) with clevis pin (12) and cotter pin (11).




5. Pull the gas spring cylinder through the opening in the top cover (7). Rest the cylinder on the top cover and attach the cover with seven new push rivets (6).





6. Place adult upholstery (1) on table so the loose hinge blade slides into the table's attachment system. Fasten two end thumb screws and tighten all three. Replace thumb screws (2) with new ones if necessary.




7. Raise the cylinder up into the seat bracket located on the back surface of the backrest.



8. Insert the clevis pin (12) through the actuator clevis and seat bracket making sure the tab on the actuator rod is between the clevis pin and top of the cylinder. Insert cotter pin (11) into clevis pin.



9. Ensure the gas cylinder works correctly by raising and lowering the upholstered backrest several times.



10. Attach paper roll holder in desired orientation with two round thumb screws. Use new round thumb screws (9) if needed.

